

C3M-03 Canopy Latch

Parts:

Part	Quantity	Manufacturing Method
Canopy Latch Catch	1	Shearing, Braking, Welding
Grip	1	3D print
Handle Shaft	1	Bandsaw, Lathe
Handle	1	Bandsaw

Procedures:

Canopy Latch Catch

- 1. Retrieve 18 Gauge sheet metal sheets at least 40x20 mm (2)
- 2. cut sheets into shapes specified on drawing sheet
- 3. Break all edges
- 4. use sheet metal brakes to bend where necessary
- 5. weld 2 pieces together as shown on drawing sheet

Grip

1. 3D print in MAE-B 3D Prototyping Lab

Handle Shaft

- 1. Retrieve 3/4" steel rod
- 2. Cut using bandsaw to 2"
- 3. Use calipers to determine accurate stock diameter
- 4. Set up lathe and insert rod
- 5. Cut the diameter to 14.29mm (.56") over half of the rods length
- 6. Remove rod, rotate it, and insert the opposite end
- 7. Cut remaining length to .56" diameter



- 8. Use tailstock to drill a .25" through hole
- 9. Remove rod and break all edges

Handle

- 1. Retrieve 1/8" x 1/2" steel bar stock
- 2. Cut to 3" length with bandsaw
- 3. Break edges

<u>Assembly</u>

- 1. Weld handle and handle shaft together
- 2. Slide grip onto handle and secure with adhesive
- 3. (alternative to grip, dip handle in rubber coating)
- 4. Adhere opposite end of shaft into hole on underside of the release button
- 5. Removal of some material on the OTS assembly may be necessary